

## E-Pass / E-Pass / E-Pass Locker Locks / Schließfachschlösser / Locker sloten

### EP1750HL

- EN • Software: long time users, mounted horizontal
- DE • Software: Dauernutzer, horizontale Montage
- NL • Software: langdurige gebruikers, horizontaal gemonteerd

### EP1750HU

- EN • Software: long time users, mounted vertical
- DE • Software: Dauernutzer, vertikale Montage
- NL • Software: langdurige gebruikers, verticaal gemonteerd

### EP1760HL

- EN • Software: hotel mode, mounted horizontal
- DE • Software: Hotelversion, horizontale Montage
- NL • Software: hotelversie, horizontaal gemonteerd

### EP1760HU




- EN • Software: hotel mode, mounted vertical
- DE • Software: Hotelversion, vertikale Montage
- NL • Software: hotelversie, verticaal gemonteerd



EP1750HL / EP1760HL



EP1750HU / EP1760HU

ACCESSORIES / ZUBEHÖR / ACCESSOIRES				
		<span style="border: 1px solid black; padding: 0 2px;">EN</span>	<span style="border: 1px solid black; padding: 0 2px;">DE</span>	<span style="border: 1px solid black; padding: 0 2px;">NL</span>
EP9010		Spindle E-Pass, length 70 mm	Spindel E-Pass, Länge 70 mm	Spindel E-Pass, lengte 70 mm
EP9040		Cam, length 45 mm	Riegel, Länge 45 mm	Cam, lengte 45 mm
EP9045		Cam, length 45 mm	Riegel, Länge 45 mm	Cam, lengte 45 mm
EP9050		Cam, length 54 mm	Riegel, Länge 54 mm	Cam, lengte 54 mm

## E-Pass / E-Pass / E-Pass

### Locker Locks / Schließfachschlösser / Locker sloten

MECHANICS / MECHANIK / MECHANISCH			
	EP1750	EP1760	
EN	Opening	Manual	Manual
	Locking	Manual	4-digit code to close
	Blocking element	Solenoid	Solenoid
	Mounting dimensions	Not standard	Not standard
DE	Öffnen	Manuell	Manuell
	Schliessen	Manuell	Per 4-stelligem Code
	Blockierung	Elektromagnet	Elektromagnet
	Befestigungsmaße	Kein Standard	Kein Standard
NL	Openen	Handmatig	Handmatig
	Sluiten	Handmatig	Met 4-cijferige code
	Blokkeer element	Solenoid	Solenoid
	Bevestigingsmaten	Niet standaard	Niet standaard

ELECTRONICS / ELEKTRONIK / ELEKTRONISCH				
	EP1750	EP1760		
EN	<b>Power supply</b>	9V Alkaline Duracell Procell- or Energizer battery		
EN	Software	Opening Codes	10 (6-digit)	2
		Manager Codes	1	1
		Users Codes	9 (6-digits)	1 (4-digits)
		Time delay	Yes	No
		Battery low signal	Yes	Yes
		Manipulation protection	5 minute lockout after 4 consecutive wrong codes	
DE	<b>Stromversorgung</b>	9V Alkaline Duracell Procell- oder Energizer Batterie		
DE	Software	Öffnungscodes	10 (6-stellig)	2
		Managercodes	1	1
		Benutzercodes	9 (6-stellig)	1 (4-stellig)
		Öffnungsverzögerung / Öffnungsfenster	Ja	Nein
		Signal Batterie schwach	Ja	Ja
		Manipulationssperre	5 Minuten Sperre nach 4 Falscheingaben	
NL	<b>Stroomvoorziening</b>	9V Alkaline Duracell Procell- of Energizer batterij		
NL	Software	Openingscodes	10 (6-digit)	2
		Managercodes	1	1
		Gebruikerscodes	9 (6-digit)	1 (4-digit)
		Tijdvertraging	Ja	Nee
		Signaal zwakke batterij	Ja	Ja
		Manipulatieblokkering	Na 4 foutieve ingaves, 5 minuten blokkeerperiode	